





Total Mass = 4.1 lbs.



lbs.

PCB mass calculated as (Thickness x Concentration x Density) / 1x10<sup>6</sup>  
Where: Thickness = sediment thickness (yds.)  
Concentration = PCB concentration (ppm)  
Density = sediment density (lbs./cu. yd.)



Deposit N

### FIGURE F16

PCB Mass - Phase I (Postdredge)  
Thiessen Polygons

Scale: AS SHOWN	Date: April, 2000
Prepared By: Foth & Van Dyke	By: SGL
97w027	